


Software Install Procedure (XP)

Insert CD to CD-ROM

1. Autorun "Installation screen" (If it does not work automatically. Please enter the CD file and execute AUTORUN.EXE). Choose "Install Photo Express 3.0"



Select language and press OK




Install the program automatically.




Software Install Steps


After installed, please press NEXT for next step.




After confirm then press YES to continue.




Choose install patch and press NEXT to continue installation.




Choose typical or option.



After confirm, press NEXT to continue installation.



After confirm, press NEXT to continue installation.




Program will be installed automatically.



Software Install Steps


After confirmation, press NEXT (You can choose blank and decide whether to implement the following steps.)



2. Autorun “Installation screen” (If it is now executed automatically, please enter into CD and execute AUTORUN.EXE). Choose **”Install DigiCam Driver”**




Implemented automatically



Software Install Steps

After installation, choose NEXT to continue implement.



After the installation is finished, please restart the computer.

